


# DS604 TX Daspi 433/868 Mhz

Frequencies below 433 MHz are forbidden in Europe. They are just allowed in countries where they are authorized. Any handling and use of these ones are at buyer's responsibility.

In compliance with DIRECTIVE 2014/53/EU MANUFACTURED BY /FAB: ESB06450563

## USER MANUAL MODEL TX INSTALLER



### TECHNICAL FEATURES


- ✓ Model TX DASPI
- ✓ 1 battery 2450
- ✓ 4 Channels

### Programming Instructions

1. Open programming into the receiver
2. Press the button you want to program.

NOTE: THIS REMOTE HAS DASPI CONFIGURATION BY DEFAULT.

### Figure for location of battery




# DS604 TX Daspi 433/868 Mhz

Las frecuencias por debajo de 433 MHz están prohibidas en Europa, solo se permiten en los países donde están autorizados, cualquier uso o manejo de estas frecuencias es responsabilidad del comprador.

En cumplimiento de la DIRECTIVA 2014/53/EU

MANUFACTURED BY /FAB: ESB06450563



## MANUAL MODELO TX INSTALLER



### CARACTERÍSTICAS TÉCNICAS

- ✓ Modelo TX DASPI
- ✓ 1 Batería 2450
- ✓ 4 Canales

### Instrucciones de programación.

1. Abra programación en el receptor.
2. Presione el botón del mando que quiera programar.

NOTA: ESTE MANDO VIENE CONFIGURADO DE FÁBRICA PARA TRABAJAR CON DASPI.

### Imagen para ubicar la batería.



BATERIA